



Advanced Marine Decking Ltd
Unit D Deacons Boatyard
Bridge Road
Bursledon, Hants
SO31 8AW

USING SABA SEALTACK 751 TO FIT DECKING

- **CLEAN THE SUB-DECK. GRP DECKS – CLEAN WITH ACETONE, CHANGING THE RAG REGULARLY. SAND WITH 60 GRIT IF NECESSARY. STEEL DECKS – SEEK SPECIALIST ADVICE.**
- **APPLY SEALTACK 751 TO SUB-DECK USING A 4MM COMB HELD UPRIGHT. ONCE THE ADHESIVE HAS BEEN APPLIED, COMB ACROSS, WITH COMB HELD UPRIGHT, IN THE DIRECTION OF THE PLANKS. WIPE THE BACK OF THE FLEXITEEK PANEL WITH A DAMP RAG, THEN USE A ROLLING TECHNIQUE TO LAY THE DECK DOWN ONTO THE ADHESIVE. THEN USE A ROLLER OR HEAVY FLAT WEIGHT TO EXPEL ANY AIR FROM UNDER THE DECK, WORKING FROM THE MIDDLE OUT.**
- **MAKE SURE THE DECKING IS LAID BEFORE THE SEALTACK SKINS OVER – APPROX 15 MINUTES.**
- **APPLY WEIGHTS ACROSS THE DECK AS REQUIRED. TAPE DOWN EDGE AS NECESSARY.**
- **CLEAN UP EXCESS ADHESIVE FROM EDGES ONCE IT HAS CURED.**

UK Distributors for:

FLEXITEEK

E mail: sales@advancedmarinedecking.co.uk
Tel: 02380 405550 Fax: 0870 762 7024
Co. Reg. 5734198

